



Follow these steps to set up your eero system and enjoy fast, reliable Wi-Fi in minutes.

Profiles: Create profiles so that you can set custom schedules, control internet access, and apply content filters by profile. Create a profile from the Home tab in the eero mobile app.




Guest Network: eero allows you to use a guest network to share your home wifi with others.

Note: You can disable the guest network at any time by following the steps below and toggling Enable to Off. Any devices connected to the guest network will lose connectivity.



Pausing Wi-Fi Devices: Pause your wifi network by setting schedules for specific profiles or devices.



Update Password: Easily change your wifi network password as needed.



1.

From the Settings tab, select WiFi password.



2.

Tap Edit password to change your password.



3.

Enter in your new password, and tap Save.

Software Update: Help ensure your wifi network is always up to date.

Note: If there is a software upgrade available for your network, follow these instructions to start the upgrade process.




1.

From the Settings tab, select Software updates.



2.


Tap Install Now.



3.


Tap Yes, update now to update your system.

Notifications: Manage which notifications you receive in the eero mobile app.



1.

From the Settings tab, select Notifications.



2.

Customize notifications to your liking.